

## Spare Parts Clamp

Pos.	Part no.	Quantity	Description	Type	Flag <sup>1</sup>
30	202921	1	cylinder bottom	K 16.1 45°	
	202922	1	cylinder bottom	K 16.1 60°	
	202923	1	cylinder bottom	K 16.1 75°	
	202924	1	cylinder bottom	K 16.1 90°	
	202925	1	cylinder bottom	K 16.1 96°	
	202926	1	cylinder bottom	K 16.1 105°	
50		1	o-ring	12.00 x 2.00	RD
70	272740	1	clamp arm complete A17	K 16.1 Z A17	
	272741	1	clamp arm complete A18	K 16.1 Z A18	
	272742	1	clamp arm complete A19	K 16.1 Z A19	
80		1	strap	PKS 16	R
90		1	roller	DIN 5402-3-B4,0x27,8-G2	R
95		1	bush	PKS 16.1	R
100		1	roller	DIN 5402-3-B4,0x9,8-G2	R
110		1	drive shaft	K 16 Z	R
120		2	roller	PKS 16	R
200		1	scraper ring	EL 0058 N 3767 D6-D11,2x5	RD
210		1	o-ring	10.00 x 2.00	RD
220		1	o-ring	5.00 x 1.50	RD
360		2	bush	7-9x8	R

## spare parts sets / accessories

Pos.	Part no.	Quantity	Description	Type	
	457330	1	repair kit	K 16.1 Z	
	214305	1	seal kit	K 16.1	
400	368428	2	end position sensor T23	PKS 16.1 – 25	

<sup>1</sup> R = included with repair kit, D = included with seal kit  
Subject to technical modifications.

